210 W. Campus Drive, Suite B





Arlington Heights, IL 60004 (847) 215-9490 | Fax (847) 590-1728

www.ehls.com

## **Trouble-shooting Checklist for Vertical Platform Lift (VPL)**

## 1. If VPL is at top or bottom:

- Key is turned on.
- Emergency stop switch is pulled out.
- Gate or door is closed tight.
- Check under safety panel by pushing up several times.
- Check if VPL is plugged in and circuit breaker is not tripped.

## 2. If the VPL is at the top and the platform went down two inches and then stopped:

 Make sure gate / door is closed and locked. (You may have to jiggle the gate / door)

## 3. If the VPL is at the bottom:

- Check to ensure that the key is turned on.
- Check to ensure that the emergency stop switch is pulled out.
- Check to make sure the VPL is plugged into the electrical outlet and or that the circuit breaker has not tripped.